

Remote Control Unit For VR4 and SR4

KEYPAD KEYS function:

KEYPAD FUNCTIONS:

Power.... Turn power on/off.
Title Select title to play.
Display ... Turn ON/OFF OSD display.
Mute Turn ON/OFF audio output
Repeat ... Repeat the file being played.
A-B Select a portion of the video clip and loop it. Press once to select the start, press again to select the end. The portion will automatically loop. To cancel the selection press the button again.
Search ... NOT USED.
Program NOT USED.
Clear Clear the entry.
Slow Slow playback speed.
Setup ... Shows the main menu screen.
Zoom ... NOT USED.
Arrow UP.. Move up the selection bar.
Arrow Down ... Move down the selection bar.
Arrow Left ... Move selection bar to the left.
Arrow Right ... Move selection bar to the right.
Enter ... Play the selection.
Audio Select the Audio channel.
Sub Title ... Turn sub title ON/OFF.
Step .. Advance to the next frame.
Stop ... Stop playback.
Rev ... Fast rewind.
FF ... Fast forward.
Prev .. Play previous file.
Next .. Play next file.



Akman Inc

www.akman.com

Tel: (407) 948 0562 Fax (321) 459 1086